


TC50.60




Jollybug™

EN

Owner's Manual



TC50



TC60

Read and save this instruction manual before
allowing your child to use this product !



1. SAFETY WARNINGS

GENERAL WARNING:


- Please, read these instructions before using this product for the first time, and keep them for later reference.
- Failure to follow these instructions closely could jeopardise your child's safety.
- To ensure your child's safety, it is important to know exactly how this product works.
- This product must be assembled and dismantled by an adult.
- Before riding, make sure the product is correctly assembled and with all parts perfectly fitted together.
- Make sure you check on the nuts and bolts periodically, in order to keep them tightly fastened and thus avoid any potential danger.
- **WARNING!** Never leave your child unattended, even when using safety belts.
- Always use under adult supervision.
- Children must wear shoes and a helmet when using this product.
- Only one child at a time should use this product.
- **WARNING!** Do not use in dangerous places such as public roads, near a swimming pool or any other body of water, on sloped roads, or near an escalator or staircase.
- Use caution to avoid collision injuries and falls to the user or third parties.
- Warning. Protective equipment should be worn. Not to be used in traffic.
- Warning!  **CHOKING HAZARD**-Small parts not for children under 3 years..
- Choking hazard.
- Made in China
- Keep this information.
- This toy must be assembled by an adult!

Model Number: TC50. TC60
EN71-1-3, Phthalate APPROVAL
Maximum rider weight: 25 kgs (55 LBS).
Age: 1-4 Years.


Note: When self-locking nuts and other self-locking fixings may lose their effectiveness.

2. PARTS AND COMPONENTS

1 TC50



2 TC60




3. ASSEMBLY INSTRUCTIONS


a. Assembling the handlebar

1. Insert the handlebar into the rotate caster.
2. Tighten up the screw with crosshead Allen key (right and left side).

• TC50




• TC60




b. Assembling the rotate caster

1. Insert rotate caster into the frame.
2. Tighten up the screw nut with Allen wrench.

• TC50



• TC60




c. Replacing the Wheels and Bearings

1 Front wheel

1. Insert the PU wheel into the wheel axle.
2. Tighten up the screw nut with the Open End Wrench.

• TC50

• TC60




2 Rear wheel

1. Fix the wheel and wheel seat with the axle bolts and bushes.
2. Tighten up the axle bolts with Allen wrench.

• TC50

• TC60



4. CLEANING YOUR TC50, TC60

Wipe with a damp cloth to remove dirt and dust. Do not use industrial cleaners or solvents as they may damage the surfaces. Do not use alcohol, alcohol-based or ammonia-based cleaners as they may damage or dissolve the plastic components or soften the decals or decal adhesive. Store the TC50, TC60 in a dry, dust-free place.



5. WHEELS AND BEARINGS

Under normal circumstances and conditions, the wheels and the bearings are maintenance free. Nonetheless, it is the responsibility of the owner or guardian to periodically inspect the wheels for wear and tear, the axle for proper tightness and bearings for side-to-side play and loose parts. When a wheel or wheel bearing develops play, this is an indication of excess wear and replacement is necessary. Replace immediately with only JDBug wheels.

Worn wheels / bearings are considered normal wear-and-tear and are not covered by the JDBug Warranty. Wheels other than JDBug wheels may not be compatible with your JDBug TC50, TC60. The use of anything other than JDBug replacement parts may affect your safety and will void your warranty.


6. HOW TO RIDE

• TC50



Swing the handlebar to move forward

•TC60



Swing the handlebar to move forward

7. SAFETY CONTROL

- Always inspect TC50, TC60 prior to riding.
- Make sure bolts on handlebar and wheels are tightened securely.
- Adjust the handlebar on the suitable length for your children.

8. SAFETY REMINDERS

Loose Parts

Check and secure all fasteners before every ride. Make sure the steering bolts and foot steppers are tight. There should not be any unusual rattles or sounds from loose parts or broken components. If you are not sure, ask an experienced mechanic to check.



Safety Gear

Always wear proper protective equipment such as an approved safety helmet, elbow pads and kneepads.
Always wear shoes (lace-up shoes with rubber soles), never ride barefooted or in sandals, and keep shoelaces tied and out of the way of the wheels.

9. LIMITED WARRANTY

This Limited Warranty is the only warranty for JDBug TC50, TC60. There is no other express or implied warranty. The manufacturer warrants this product to be free of manufacturing defects for a period of six months from date of purchase. This Limited Warranty does not cover normal wear and tear, nor any damage, failure or loss caused by improper assembly, maintenance, storage or use of the scooter. This Limited Warranty will be void if the product is ever:

- a. Used in a manner other than for recreation or transportation;
- b. Modified in any way;
- c. Rented.

Check local laws and regulations to see where you may ride your scooter legally. The manufacturer is not liable for incidental or consequential loss or damage due directly or indirectly from the use of this product.

To obtain service under this warranty you must, within the warranty period, contact local distributor or by e-mail through JDBug website www.jdbug.com. JDBug will provide warranty replacement at its sole discretion. Specifications subject to change without notice.



www.jdbug.com